

### 3.13.3 Far End Control

---

It is possible to get some control of the far end system. This means that you can control your conference partner's camera, video sources and presets. You can also request a snapshot from the far end side. Enabling Far End Control in the Control Panel will put the system in Far End mode and camera control, camera preset, presentation, and snapshot will work on the far end camera.

Far End Control only works when you are in call and if the far end side supports H.281 (Far End Camera Control). You can prevent others from controlling your system by setting Allow Far End Camera Control to Off in Control Panel - Administrator Setting - General - Permissions (see 4.1.6 [Permissions](#) for details).

#### **How to use Far End control:**

There are two ways of enabling the far end camera control when in a call and if supported by the far end:

1. Open the Control Panel. Enable Far End Control by selecting the Far End button in the Control Panel. A green circle indicates that the Far End button is activated. Now you are in Far End mode and can use camera control, camera preset, presentation and snapshot for the far end. To turn Far End control off, go to the control panel again and press Far End again. The green circle disappears.
2. Select the "Move Camera" in the menu and you will have a selection for near and far end camera control. If far end camera control is selected this will give you control of the far end camera. Press OK on the remote to exit far end camera control.

#### **Far End Camera Presets**

Far End Camera Presets works just like your own camera presets. When Far End is on, use the number keys to activate far end camera presets. You are however not allowed to save far end camera presets.

#### **Far End Presentation**

Pressing the Presentation key or choosing a presentation from the presentation menu while Far End is on, will result in opening a far end presentation. Be aware of that the far end video sources may not correspond with the buttons in the presentation menu. If you press Document Camera, the far end side might have another video source on this input.

#### **Request snapshot from the Far End**

You can request a snapshot from the far end side. Put the system in Far End mode and press Snapshot on the remote control to take a snapshot of the current far end video (current is default snapshot source).